Menu

SCHEDA ATTREZZATURA PER MANUTENZIONE POMPE SERIE 51 - ALBERO FEMMINA
MAINTENANCE TOOL CHART FOR PUMPS 51 SERIES - FEMALE SHAFT

PARTICOLARE DA SOSTITUIRE *PART TO REPLACE*		**ATTREZZO ESTRAZIONE** *REMOVING TOOL*			**ATTREZZO INSERIMENTO** *INSERTION TOOL*		
CODICE *PART NO.*	**DESCRIZIONE** *DESCRIPTION*	**CODICE** *PART NO.*	**DESCRIZIONE** *DESCRIPTION*	**UTILIZZARE CON** *USE WITH*	**CODICE** *PART NO.*	**DESCRIZIONE** *DESCRIPTION*	**UTILIZZARE CON USE WITH**
90156500	OIL SEAL D. 15x24x5				26242200	OIL SEAL INSERTION TOOL	
90357200	OR Ø5,28x1,78 (2021)				26242300	O-RING MOUNTING GUIDE	
90261800	PACKING D. 15x25x5/3,1 P.	26407400	PACKING EXTRACTION SOCKET D. 15	USE WITH EXTRACTOR 26019400	26242400	PACKING INSERTION GUIDE	USE WITH DRIVE STUD 26242500
90262000	PACKING D. 15x25x5/3,1 H.P.	26407400	PACKING EXTRACTION SOCKET D. 15	USE WITH EXTRACTOR 26019400	26242400	PACKING INSERTION GUIDE	USE WITH DRIVE STUD 26242500
90268100	PACKING D. 18x26x5/3	27124900	PACKING EXTRACTION SOCKET D. 18	USE WITH EXTRACTOR 26019400	27508100	PACKING INSERTION GUIDE	USE WITH DRIVE STUD 26242500
90164400	OIL SEAL. 30x42x7				27910200	OIL SEAL INSERTION TOOL	