Menu

66LP Series Tool Chart

SCHEDA ATTREZZATURA PER MANUTENZIONE POMPE SERIE 66
MAINTENANCE TOOL CHART FOR PUMPS 66 SERIES

PARTICOLARE DA SOSTITUIRE *PART TO REPLACE*		**ATTREZZO ESTRAZIONE** *REMOVING TOOL*			**ATTREZZO INSERIMENTO** *INSERTION TOOL*		
CODICE *PART NO.*	**DESCRIZIONE** *DESCRIPTION*	**CODICE** *PART NO.*	**DESCRIZIONE** *DESCRIPTION*	**UTILIZZARE CON** *USE WITH*	**CODICE** *PART NO.*	**DESCRIZIONE** *DESCRIPTION*	**UTILIZZARE CON** **USE WITH**
90162500	OIL SEAL D. 22x32x5,5				27385000	OIL SEAL INSERTION TOOL	
90263400	PACKING D. 16x26x9,5 H.P.	27179700	PACKING EXTRACTION SOCKET D.16	USE WITH EXTRACTOR 26019400	27385500	PACKING INSERTION GUIDE	USE WITH DRIVE STUD 26242500
90265500	PACKING D. 18x28x10 H.P.	27124900	PACKING EXTRACTION SOCKET D.18	USE WITH EXTRACTOR 26019400	27385300	PACKING INSERTION GUIDE	USE WITH DRIVE STUD 27385200
90269200	PACKING D. 20x30x10 H.P.	26093400	PACKING EXTRACTION SOCKET D.20	USE WITH EXTRACTOR 26019400	27396300	PACKING INSERTION GUIDE	USE WITH DRIVE STUD 27385200
90271700	PACKING D. 22x32x10 H.P.	26093500	PACKING EXTRACTION SOCKET D.22	USE WITH EXTRACTOR 26019400	27385100	PACKING INSERTION GUIDE	USE WITH DRIVE STUD 27385200
90274100	PACKING D. 24x34x10 H.P.	26093600	PACKING EXTRACTION SOCKET D.24	USE WITH EXTRACTOR 26019400	27396400	PACKING INSERTION GUIDE	USE WITH DRIVE STUD 27385200
90164800	OIL SEAL D. 30x55x7				26083600	OIL SEAL INSERTION TOOL	

66HP Series Tool Chart

SCHEDA ATTREZZATURA PER MANUTENZIONE POMPE SERIE 66 H.P.
MAINTENANCE TOOL CHART FOR PUMPS 66 H.P. SERIES

PARTICOLARE DA SOSTITUIRE *PART TO REPLACE*		**ATTREZZO ESTRAZIONE** *REMOVING TOOL*			**ATTREZZO INSERIMENTO** *INSERTION TOOL*		
CODICE *PART NO.*	**DESCRIZIONE** *DESCRIPTION*	**CODICE** *PART NO.*	**DESCRIZIONE** *DESCRIPTION*	**UTILIZZARE CON** *USE WITH*	**CODICE** *PART NO.*	**DESCRIZIONE** *DESCRIPTION*	**UTILIZZARE CON** **USE WITH**
90162500	OIL SEAL D. 22x32x5,5				27385000	OIL SEAL INSERTION TOOL	
66210166	BUSHING	26019400	EXTRACTOR				
90263400	PACKING D. 16x26x9,5 H.P.	27179700	PACKING EXTRACTION SOCKET D.16	USE WITH EXTRACTOR 26019400	27385500	PACKING INSERTION GUIDE	USE WITH DRIVE STUD 26242500
90265500	PACKING D. 18x28x10 H.P.	27124900	PACKING EXTRACTION SOCKET D.18	USE WITH EXTRACTOR 26019400	27385300	PACKING INSERTION GUIDE	USE WITH DRIVE STUD 27385200
90164800	OIL SEAL D. 30x55x7				26083600	OIL SEAL INSERTION TOOL	