14”
WHIRL-A-WAY

OPERATION MANUAL

Model #
85.403.014SS



TABLE OF CONTENTS

Introduction
4 Using the Operator's Manual

Product Identification
5 Record Identification Numbers

Pre-Operating Instructions
6 Before You Begin
6 Intended Use
6 Care

Operating
7 Operating

Recommended Applications
7 Use with a Gun and Lance
7 Attach to Long Wand

Parts List
8 Parts List

Warranty
9 Warranty



Attention: Read through the complete manual prior to the initial use of your Whirl-A-Way.

Using the Operator's manual

The operating manual is an important part of your 14" Whirl-A-Way and should be read thoroughly before initial use, and referred to often to make sure adequate safety and service concerns are being addressed.
Reading the owner's manual thoroughly will help avoid any personal injury or damage to your Whirl-A-Way. The information in this manual will offer you the most effective tools for cleaning as well as the safest. By knowing how best to operate this machine you will be better positioned to show others who may also operate the unit.
This manual contains information for the complete range of BE Whirl-A-Ways, and is placed in order starting from the safety requirements to the operating functions of your pump. You can refer back to the manual at any time to help troubleshoot any specific operating functions, so store it with the machine at all times.

14” Whirl-A-Way

If you need to contact an Authorized Dealer or Customer Service line (+61-02-4577-2144) for information on servicing, always provide the product model and identification numbers.

You will need to locate the model and serial number for the pump and record the information in the places provided below.

Date of Purchase:

Dealer Name:

Dealer Phone:

Model Number:

Pre-Operating Instructions

Before You Begin

Prior to initial operation of the unit carefully read the information outlined in the operation instructions.

- Ensure that all components are in good working order and that they operate safely.
- Do not use cleaner if any part is not in proper working condition.
- No modifications permitted on the machine.
- Before operation test the cleaner at low pressure (1500 PSI) to ensure you can operate safely at high pressures.

⚠ WARNING
This product uses extreme water pressure and water force. This may cause kickback when using the cleaner.

The surface Cleaning System you have purchased connects directly to a 1/4" quick connect coupler, operating to a maximum of 4000 PSI.

This 14' Whirl-A-Way is designed to operate with cold water pressure washers. We do not recommend the use of hot water as the nylon brush skirt will soften and wear prematurely, voiding any warranty.

Before operation ensure that the pressure washer is on low pressure when first using the Whirl-A-Way. Adjust pressure with adjustable unloader.

Intended Use

The Whirl-A-Way is suitable for cleaning floors and walls in conjunction with a high pressure cleaner.

(A) Recommend Operating pressure: 3000-4000 PSI
(B) Maximum pressure: 4000 PSI
(C) Maximum water temperature: 85°C/180°F

- Never exceed maximum operating pressure and temperature.

Care

- Protect from frost/ freezing.
- Ensure bristles are not deformed during storage.

Please dispose of packaging environmentally responsibly
The packaging materials are recyclable. Please do not throw the packaging in the household rubbish but take it to a recycling centre.

Operating

Never reach under the unit while the high-pressure cleaner is operating
- Never direct the 14" Whirl-A-Way at humans or animals.
- Do not operate on a ladder.

WARNING
Nozzle has been set according to factory set alignment.

During operation, should you experience a buildup of small stones or other foreign material within the cover, we recommend that you simply tip the cleaner on its side at 45° which should expel any foreign materials. This extend the life of your tips and swivel arm. The tips that have been installed on your surface cleaning system permit the use of your cleaner with a pressure washer producing up to 3 GPM at 4000 PSI. This unit will not spin efficiently with pressure under 2.3 GPM. Periodically check the tips to ensure they are not plugged by dirt particles. It is very important when operating your 14" Whirl-A-Way, that you maintain a continuous motion.

Should you leave the cleaner in a stationary position, the surface being cleaned can be seriously damaged by the high pressure.

Recommended Applications

use with a gun and lance

Connect to lance using q/c fittings on the lance and 14" Whirl-A-Way.

Attach to long wand


Attach to a longwand for cleaning hard to reach surfaces. Connect to longwand using the QC fittings on the longwand and 14" Whirl-A-Way.

For 4GPM, use #020 nozzle

For 3GPM, use #015 nozzle

Parts List

A. Durable Nylon Brush Skirt, Stainless
B. Stainless Steel Cover
C. 4,000PSI Rotary Head, 180°F
D. Castor Bracket
E. Plastic Castor, Grey
F. Rotary Arm



Warranty

The rotary head has a six-month warranty from the date of purchase. Should you encounter problems with the rotary head within that time period, contact the place of purchase for RGA and return with authorized RGA. If you encounter problems after the six month period has lapsed, a rotary head repair kit is available. You can use this kit to replace the components inside the rotary head very quickly.

There is no warranty on the nylon brush ring.

All other components of the surface cleaning system have a 30-day replacement warranty against manufacturer's defects only.

If you need assistance with the assembly or operation of this Whirl-A-Way please call

1-866-850-6662